

Work Order ID 83404

83404

Page 1

April-17-12 4:10:14 PM

Item ID: D206-642-511

Accept

N900040100

Setup Start *NS1*

Revision ID:

Stop *NS2*

Item Name: Float Skidtube LH

Start Date: 17/04/2012 Start Qty: 1.00

1

Cust Item ID:

Required Date: 26/04/2012 Req'd Qty: 1.00

1

Customer:

Reference:

Approvals: Process Plan: *MLS*

Date: 12/04/12 Tooling:

Date:

Run Start *NR1*

QC:

Date: SPC (Y/N):

Date:

Stop *NR2*

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr

Revision Nbr

INN-D206-642

0

100

0.00

100

DOCUMENT CONTROL

DC

Memo

0.00

Document Control

Photocopy bluefile and create labels per PPP D206-642-511CHG004

110

Pick Kit

0.00

110

Packaging

Memo

0.00

Packaging

120

QC4- 100% Inspect kits for completeness

0.00

120

QC

Memo

0.00

Quality Control

DAS 16 9-89 *12/4/12*

12/4/12 MLS 12-7-31

12/4/12 10

85363

DAS 16 9-89 *12/4/12*

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Work Order ID 83404***83404***

Page 2

April-17-12 4:10:14 PM

Item ID: D206-642-511

Accept

N900040100Setup Start ***NS1***

Revision ID:

Stop ***NS2***

Item Name: Float Skidtube LH

Start Date: 17/04/2012 Start Qty: 1.00

1

Cust Item ID:

Required Date: 26/04/2012 Req'd Qty: 1.00

1

Customer:

Reference:

Approvals:

Process Plan:

Date:

Tooling:

Date:

Run Start ***NR1***

QC:

Date:

SPC (Y/N):

Date:

Stop ***NR2***Sequence ID/
Work Center IDOperation
DescriptionSet Up/
Run HoursTool ID Tool # Plan
Code Accept Reject Reject Insp.
Qty Qty Number Stamp

130

0.00

130

Packaging

0.00

Packaging

Memo

Packaging

Identify and pack for shipping as per PPP D206-642-511

Location: 72*12/17/31 @*

140

0.00

140

QC21- Final Inspection - Work Order Release

0.00

QC

Memo

Quality Control

*12/17/31 @**NOV 12 2013*

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Picklist Print

April-17-12 4:10:17 PM

Page 1

Work Order ID: 83404

83404

Parent Item: D206-642-511

D206-642-511

Parent Item Name: Float Skidtube LH

Start Date: 17/04/2012

Required Date: 26/04/2012

Start Qty: 1.00

Required Qty: 1.00

Comments:

IPP Rev:B05.09.23 Revised per D206-642 Rev. JKJ/JLM
IPP Rev:C 07-02-23 As per IIN D206-642 Rev K JLM
IPP rev D 07.06.06 added K642-511 EC
IPP Rev:E 07-12-05 ECN 1080p Rev L DD verified by:

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
---------------------------------	------------------------	---------------	-------------	---------------------	------------------	-----------------	--------------------	----------------	-------------	--------------	---------------	----------------	--------

D206-642-541

Manufactured

No

110

Each

0.0000

1

1

D206-642-541

Replacement Skidtube

K642-511

Manufactured

No

110

Each

1.0000

1

1

K642-511

saddle kit 642-511

CHG

**

85363

**

82557

Location

Loc Qty

Loc Code

PKG

1

75060

1

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries